

mitsubishi

TRANSISTORIZED INVERTER

– INSTRUCTION MANUAL –

MELSECNET/mini-S3

FR-A5NN

Thank you for choosing the Mitsubishi transistorized inverter option unit.

This instruction manual gives handling information and precautions for use of this product. Incorrect handling might cause an unexpected fault. Before using the equipment, please read this manual carefully to use it to its optimum.

Please forward this manual to the end user.

Safety Instructions

Do not attempt to install, operate, maintain or inspect this product until you have read through this instruction manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this manual, the safety instruction levels are classified into "WARNING" and "CAUTION".



WARNING

Denotes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



CAUTION

Denotes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the CAUTION level may lead to a serious consequence under some circumstances. Please follow the instructions of both levels as they are important to personnel safety.

SAFETY INSTRUCTIONS

1. Electric Shock Prevention

 **WARNING**

- While power is on or when the inverter is running, do not open the front cover. You may get an electric shock.
- Do not run the inverter with the front cover removed. Otherwise, you may access the exposed high-voltage terminals and charging part and get an electric shock.
- If power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.
- Before starting wiring or inspection, switch power off, wait for more than 10 minutes, and check for no residual voltage with a tester or the like.
- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.
- Always install the option unit before wiring. Otherwise, you may get an electric shock or be injured.
- Operate the switches with dry hands to prevent an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise, you may get an electric shock.

2. Injury Prevention

 **CAUTION**

- Apply only the voltage specified in the instruction manual to each terminal to prevent damage, etc.
- Ensure that the cables are connected to the correct terminals.
Otherwise damage, etc. may occur.
- Always make sure that polarity is correct to prevent damage, etc.
- While power is on or for some time after power-off, do not touch the inverter as it is hot and you may get burnt.

3. Additional instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.:

(1) Transportation and installation

CAUTION

- Do not install or operate the option unit if it is damaged or has parts missing.
- Do not stand or rest heavy objects on the product.
- Check that the mounting orientation is correct.
- Prevent screws, metal fragments, conductive bodies, oil or other flammable substance from entering the inverter.

(2) Test operation and adjustment

CAUTION

- Before starting operation, confirm and adjust the parameters. A failure to do so may cause some machines to make unexpected motions.

(3) Usage

WARNING

- Do not modify the equipment.

 **CAUTION**

- When parameter clear or all parameter clear is performed, each parameter returns to the factory setting. Re-set the required parameters before starting operation.
- For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.

(4) Maintenance, inspection and parts replacement

 **CAUTION**

- Do not test the equipment with a megger (measure insulation resistance).

(5) Disposal

 **CAUTION**

- Dispose of this product as general industrial waste.

(6) General instruction

All illustrations given in this manual may have been drawn with covers or safety guards removed to provide in-depth description. Before starting operation of the product, always return the covers and guards into original positions as specified and operate the equipment in accordance with the manual.

CONTENTS

1 PRE-OPERATION INSTRUCTIONS	1
1.1 Unpacking and Product Confirmation	1
1.2 Packing Confirmation	1
1.3 Structure	2
1.4 Features	4
1.5 Instruction	4
2 INSTALLATION	5
2.1 Pre-Installation Instructions	5
2.2 Installation Procedure	5
3 WIRING	7
3.1 Wiring Example	7
3.2 Optical Fiber Cables	8
3.2.1 Connection of optical fiber cables	8
4 PRE-OPERATION PROCEDURES	12
4.1 Pre-Operation Settings and Procedures	12
4.2 Instructions	13
4.3 Inverter Station Number Setting	14
4.4 Operation Modes of the Inverter	15
4.5 Setting of Control Place for Inverters	19

5 FUNCTIONS	21
5.1 Function Block Diagram	21
5.2 Functions	23
6 PROGRAMMING USING THE PC	26
6.1 Programming	26
6.1.1 Explanation of I/O signals	27
6.2 Buffer Memory	30
6.3 Programming Procedure	39
6.4 Programming Examples	41
6.5 Setting Items and Set Data	56
7 ALARM	60
7.1 Alarm	60
8 SPECIFICATIONS	63
8.1 Performance Specifications	63
8.2 Optical Fiber Cable Specifications	64
8.3 Inverter I/O Delay Time	64

1. PRE-OPERATION INSTRUCTIONS

1.1 Unpacking and Product Confirmation

Take the option unit out of the package, check the unit name, and confirm that the product is as you ordered and intact.

Note: This product may be used with inverters manufactured during and after November, 1997.

The inverter may be used with this unit if its SERIAL number indicated on the rating plate and package plate has the following version or later. (The SERIAL number on the package plate uses the 3 most significant digits of the following 6-digit control number and is indicated in 6 digits including the version symbol.)

Model	SERIAL Number
FR-A520-0.4K, 0.75K, 11K to 22K	R7Y0000000
FR-A520-1.5K to 7.5K	Q7Y0000000
FR-A520-30K to 55K	G7Y0000000
FR-A540-0.4K to 22K	G7Y0000000

R 7 Y 000000
Symbol Year Month Control number

SERIAL number


SERIAL is made up of 1 version symbol and 8 numeric characters as shown above.

1.2 Packing Confirmation






Make sure that the package includes the following accessories:

- Instruction manual 1
- Mounting screws M3 × 8 4

1.3 Structure



(1) Nomenclature

Name	Function
Optical cable connector	Used to connect optical cables. Always connect the cables for MINI link. RD·······Receive cable SD·······Transmission cable
Station number setting switches	 <p>Used to set the inverter station number between 1 and 61. For details, refer to page 14.</p>
Operating status indicator LEDs	<p>  RD ······ Lit during data receive. Dimly lit to indicate normal state.*  ERR ······ Lit to indicate receive data error. Extinguished to indicate normal communication.  SD ······ Lit during data transmission. Dimly lit to indicate normal state.*  RUN ······ Lit to indicate normal data transmission with the master station. *: Extinguished to indicate alarm. </p>

1.4 Features

A programmable controller data link system (referred to as the "PC link") can be configured by connecting Mitsubishi transistorized inverters with the Mitsubishi MELSEC-A series general-purpose programmable controller data link system MELSENET/MINI-3 (referred to as the "MINI link") using optical fiber cables.

PC link is a system designed to control and monitor the transistorized inverters from the programmable controller at a remote location.

- (1) Factory Automation can be easily applied to inverters which are used as remote I/O stations in the MINI link system and are controlled and monitored by PC user programs.
- (2) Various set values, such as motor acceleration/deceleration time, can be changed and checked from the PC.
- (3) By using the AJ71PT32-S3 data link module as the master station, up to 16 inverters may be connected to the PC (if only inverters are connected).
- (4) There is no need to worry about noise as optical cables are used to connect inverters in the PC link.
- (5) The PC link unit is fitted to the connector in the inverter to ensure ease of installation and a saving of installation space.
- (6) Plastic fiber cables are used as the optical fiber cables. Optical cable connectors can be machined easily by the user with a special-purpose tool kit.

1.5 Instruction

- (1) In this manual, the link with the programmable controller is referred to as the "PC link".

2. INSTALLATION

2.1 Pre-Installation Instructions

(1) Make sure that the input power of the inverter is off.


 **CAUTION**

 **With input power on, do not install or remove the option unit. Otherwise, the inverter and option unit may be damaged.**

2.2 Installation Procedure


- (1) Securely insert the connector of the option unit into the connector of slot 3 of the inverter. At this time, also fit the option fixing holes correctly. For the slot positions, refer to the next page.
- (2) Securely fix the option unit to the inverter with the accessory mounting screws. If the screw holes do not match, the connector may not have been plugged correctly. Check for loose connections.

 **CAUTION**


 **When installing the inverter front cover, the cables to the inverter's control circuit terminals and the optical fiber cables should be routed properly in the wiring space to prevent them from being caught between the inverter and its cover.**

Note: This option unit uses two slots.

For routing the optical cables, use the space on the left-hand side of the control circuit terminal block.



(Note) When fitting an option unit, push it until it is fixed with the option fixing hook securely.
 (The option fixing hooks are provided for inverters produced in and after August, 2000.)
 Note that since this option unit (FR-A5NN) uses two slots, the fixing hook of slot 1 (slot 2) will interfere with the option unit fitted to slots 1, 2 (slots 2, 3). Using nippers etc., please cut off the hook that will interfere before fitting the option unit.



Note 1. Only one option of the same type may be only be used. When two or more options are mounted, priority is in order of slots 1, 2 and 3, and the options having lower priority are inoperative. (Only one communication option may be used.)

2. When the inverter cannot recognize that the option is mounted or when two or more communication option units are mounted, "E.OPT" error is displayed. The errors shown differ with the mounting slots 1, 2, 3.

3. Remove the option unit carefully so that its connector is not damaged.

Mounting Position	Error Display
Slot 1	E.OP1
Slot 2	E.OP2
Slot 3	E.OP3

3. WIRING

3.1 Wiring Example


(1) PC side

Install the AJ71PT32-S3 to the main or extension base unit of the PC CPU used as the master station.

(2) Inverter side

Fit the MELSECNET/MINI-S3 unit (FR-A5NN) into the inverter.

(3) Connect the master station and the MELSECNET/MINI-S3 unit (FR-A5NN) with optical fiber cables.




3.2 Optical Fiber Cables

3.2.1 Connection of optical fiber cables



This section explains the connection, engagement and disengagement of optical fiber cables.

(1) Connection of PC and inverters



The station numbers of remote I/O station and PC link units may be set independently of the PC link cable connection sequence.



(2) Optical fiber cable engagement



(3) Optical fiber cable disengagement



(4) Optical fiber cables


1) Optical fiber cable handling instructions

If optical fiber cables are handled roughly, they will be damaged. Therefore:


- Do not compress the cable with a sharp edge.
- Do not twist the cable roughly.
- Do not pull the cable roughly (more than permissible tension).
- Do not stamp on the cable.
- Do not put anything on the cable.
- Do not scratch the cable sheath.

NOTE

- (1) Do not touch the optical fiber cores in the connector or optical module and protect them from dirt and dust. When not in use, always fit the protective caps to the connector and optical module to prevent a data link fault that may occur due to transmission losses.



- (2) Any optical fiber cable must not be bent within its minimum bending radius.



Handle the optical fiber cable with special care. If it is bent within its minimum bending radius, the optical fiber core may be broken, disabling the data link.
Minimum bending radius: 40mm

The following optical fiber cables conform to the required specifications and are available from Mitsubishi:

Model Code	Cable Type	Max. Interstation Distance
M-2P-□M-A	PVC coated core cable (indoor standard type, UL Standard-compliant) cable diameter 2.2mm	50m
M-2P-□M-B	Reinforced PVC coated core cable (indoor reinforced type) cable diameter 5.0mm	
M-2P-□M-C	PE coated core cable (indoor standard type) cable diameter 2.2mm	

□ in the model code indicates the length of the optical fiber cable (unit: m).


Example: PVC coated core cable of 40m

M-2P-40M-A

4. PRE-OPERATION PROCEDURE

4.1 Pre-Operation Settings and Procedures

Set the MINI link system in accordance with the following flowchart:




4.2 Instructions

- 1) During PC link operation, the inverter only accepts commands from the programmable controller and ignores any external operation command and any operation command from the parameter unit.
- 2) If the same station number is set to different inverters, wrong data will be transferred and normal communication cannot be executed.
- 3) The inverter is brought to an alarm stop "E.OP2" or "E.OP3" if data communication stops, even instantaneously, due to a programmable controller fault, an open optical cable etc., during PC link operation.
- 4) If the communication start signal (Yn+18) of the master station is switched off during PC link operation, data communication stops and the inverter is brought to an alarm stop "E.OP2" or "E.OP3".
To stop the PC link operation, switch the operation mode to the external operation once, then switch off the communication start signal (Yn+18).
- 5) When the power of any inverter is shut off, optical signals are cut off, data communication comes to a stop, and accordingly the other inverters within the same loop are also brought to an alarm stop.
To continue the data communication of the other inverters, it is recommended to separate the control power supply of each inverter from the main power supply and connect it to the inverter terminals R1 and S1. Note that when the main power is restored, the corresponding inverter is reset and returned to the external operation mode. To resume the PC link operation, set the operation mode to the PC link operation using the programmable controller program.
Note that setting "1" or "2" in Pr. 340 selects the PC link operation mode.
- 6) Do not set "1" in Pr. 77 "write inhibit selection" of the inverter. If the PC link mode is selected with this setting, all parameters will be write-inhibited. If this setting is made accidentally, switch power off once, remove the inboard option, then switch power on, and change the Pr. 77 setting to "0" or "2". Then, switch power off, mount the option, switch power on, and switch to the PC link mode.

4.3 Inverter Station Number Setting

Use the station number setting switches to set inverter station numbers. Set station numbers when I/O refresh is not being executed, noting the following:

- 1) Station numbers may be set between 1 and 61.
- 2) One inboard option occupies four stations. (four PC remote I/O stations).
For example, one inverter defined as station 1 occupies stations 1 to 4. Hence, stations 1 to 4 cannot be used by the other units.
- 3) The I/O refresh range depends on the total number of stations (buffer memory address 0) which may be calculated from the number of PC remote I/O stations and PC link units connected in the same loop.
For example, if there is one remote I/O station (there is one station as an example) and three inverters (PC link units), the total number of stations = $1 + (3 \times 4) = 13$.
- 4) Station numbers may be specified independently of the connection sequence, e.g. as shown below:




4.4 Operation Modes of the Inverter

(1) Operation modes

The inverter mounted with the PC link unit has the following operation modes:

- 1) PU operation Controls the inverter from the keyboard of the operation panel/parameter unit (FR-DU04/FR-PU04) (referred to as the "PU") installed to the inverter.
- 2) External operation Controls the inverter by switching on/off external signals to the control circuit terminals of the inverter. (The inverter is factory-set to this mode.)
- 3) PC link operation Controls the inverter in accordance with the PC user program via the MELSECNET/MINI-S3 unit (FR-A5NN).



(2) Operation mode switching

1) Operation mode switching conditions

Before switching the operation mode, check that:


- The inverter is at a stop;
- Both the forward and reverse rotation signals are off; and
- The Pr. 79 "operation mode selection" setting is correct.

(Use the parameter unit of the inverter for setting.)

Setting	Operation Mode Selection	Switching to PC Link Operation Mode
0	PU or external operation	Disallowed when the PU mode is selected. Allowed when the external mode is selected.
1	PU operation only	Disallowed
2	External operation only	Allowed
3	External/PU combined operation	Disallowed
4	External/PU combined operation	Disallowed
5	Programmed operation	Disallowed (Parameter values write-enabled in the external operation mode may be changed)
6	Switch-over	Allowed
7	External operation (PU operation interlock)	Allowed only in the external operation mode when the PU interlock signal (X12) is on.
8	PU or external (signal switching)	Allowed only in the external operation mode (X16 on).

2) Operation mode switching method

Change the operation mode as described below:



Symbol	Switching Type	Switching Method
A	PU operation → external operation	Operate the external operation key sheet on the PU.
B	External operation → PU operation	Operate the PU operation key sheet on the PU.
C	External operation → PC link operation	By the user program of the PC (refer to page 52).
D	PC link operation → external operation	By the user program of the PC (refer to page 52).
E	PU operation → PC link operation	Switching disallowed/allowed if external operation is selected in A and PC link operation is then selected in C. (Note 2)
F	PC link operation → PU operation	Switching disallowed/allowed if external operation is selected in D and PU operation is then selected in B. (Note 2)

When "1" or "2" is set in Pr. 340 "link start mode selection", the operation mode is computer link operation at power on or inverter reset.

Note: 1. When setting "1" or "2" in Pr. 340, the initial settings (station number setting, etc.) of the inverter must be made without error.
 2. In the switch-over mode, switching mode E and F is allowed.

3) Operation mode display

The operation mode is displayed on the PU as indicated below:

- PU operation PU
- External operation EXT
- PC link operation NET

4) Operation mode at power on and instantaneous power failure

By setting the Pr. 340 "link start mode selection" value as appropriate, the operation mode at power on and at restoration from instantaneous power failure can be selected.

Pr. 340 Setting	Pr. 79	Operation Mode Name	Mode at Power On or at Restoration from Instantaneous Power Failure
0	0	PU or external operation	Inverter goes into the external operation mode.
	1	PU operation only	Inverter goes into the PU operation mode.
	2	External operation only	Inverter goes into the external operation mode.
	3	External/PU combined operation	Running frequency is set in the PU operation mode and the start signal is set in the external operation mode.
	4	External/PU combined operation	Running frequency is set in the external operation mode and the start signal is set in the PU operation mode.
	5	Programmed operation mode	Inverter is operated by the program.
	6	Switch-over mode	Operation mode is switched while running.
	7	External operation mode	Shift to the PU operation mode is controlled by ON/OFF of the X12 signal.
	8	External/PU combined operation mode	Operation mode is switched by ON/OFF of the X16 signal.
1	PC link operation		Inverter goes into the PC link operation mode. (Program need not be used for switching)
2	PC link operation		Inverter goes into the PC link operation mode. (Program need not be used for switching) For computer link operation.

- The Pr. 340 value may be changed in any operation mode.
- When Pr. 79 "operation mode selection" = "0", "2", "6", "1" and "2" in Pr. 340 are made valid. When the other values are set, the Pr. 340 setting is made invalid.
- When performing MINI link operation, set "1" or "2" in Pr. 340.

⚠ CAUTION

⚠ If an instantaneous power failure occurs with "2" set in Pr. 340 "link start mode selection", the inverter continues operation in the status prior to the instantaneous power failure.

4.5 Setting of Control Location for Inverters

In the PC link operation mode, operation can be performed by signals from external terminals in accordance with the settings of Pr. 338 "operation command write" and Pr. 339 "speed command write".

Control location selection		Operation command write (Pr. 338)	0: PC	0: PC	1: External	1: External	Remarks	
		Speed command write (Pr. 339)	0: PC	1: External	0: PC	1: External		
Fixed functions (Functions equivalent to terminals)	Forward rotation command (STF)		PC	PC	External	External		
	Reverse rotation command (STR)		PC	PC	External	External		
	Start self-holding selection (STOP)		—	—	External	External		
	Output halt (MRS)		Both	Both	External	External	(Note 1)	
	Reset (RES)		Both	Both	Both	Both		
	PC link operation frequency		PC	—	PC	—		
	2		—	External	—	External		
	4		—	External	—	External		
1		Compensation	External	Compensation	External			
Selective functions	Pr. 180 to Pr. 186 settings	0	Low-speed operation command (RL)	PC	External	PC	External	Pr. 59 = 0
		1	Middle-speed operation command (RM)	PC	External	PC	External	Pr. 59 = 0
		2	High-speed operation command (RH)	PC	External	PC	External	Pr. 59 = 0
		3	Second function selection (RT)	PC	PC	External	External	
		4	Current input selection (AU)	—	Both	—	Both	
		5	Jog operation selection (JOG)	—	—	External	External	
		6	Automatic restart after instantaneous power failure selection (CS)	External	External	External	External	
		7	External thermal relay input (OH)	External	External	External	External	
		8	15-speed selection (REX)	PC	External	PC	External	Pr. 59 = 0
		9	Third function (X9)	PC	PC	External	External	
		10	FR-HC connection, inverter operation enable (X10)	External	External	External	External	
		11	FR-HC connection, instantaneous power failure detection (X11)	External	External	External	External	
12	PU external interlock (X12)	External	External	External	External			

Selective functions	Pr. 180 to Pr. 186 settings	13	External DC dynamic braking start (X13)	PC	PC	External	External	
		14	PID control valid terminal (X14)	PC	External	PC	External	
		15	Brake opening completion signal (BRI)	PC	PC	External	External	
		16	PU operation-external operation switching (X16)	External	External	External	External	
		17	Load pattern selection-forward/reverse rotation boost switching (X17)	PC	PC	External	External	
		18	Magnetic flux-V/F switching (X18)	PC	PC	External	External	
		19	Load torque high-speed frequency (X19)	PC	PC	External	External	
		22	Orientation command	PC	PC	External	External	(Note 2)
RH, RM, RL, RT selection functions			Remote setting (RH, RM, RL)	PC	External	PC	External	Pr. 59 = 1, 2
			Programmed operation group selection (RH, RM, RL)	—	—	—	—	Pr. 79 = 5 PC link operation disallowed
			Stop-on-contact selection 0 (RL)	PC	External	PC	External	Pr. 270 = 1, 3
			Stop-on-contact selection 1 (RT)	PC	PC	External	External	

[Explanation of table]

External : Control by signal from external terminal is only valid.

PC : Control from sequence program is only valid.

Both : Control from both external terminal and PC is valid.

— : Control from both external terminal and PC is invalid.

Compensation : Control by signal from external terminal is only valid if Pr. 28 (multi-speed input compensation) setting is 1.

Note 1. If the FR-HC is connected, inverter operation enable signal (X10) is not assigned when the FR-HC is used (Pr. 30 = 2) or if the PU operation interlock signal (X12) is not assigned when the PU operation interlock function is set (Pr. 79 = 7), this function is also used by the MRS signal and therefore the MRS signal is only valid for the external terminals, independently of the Pr. 338 and Pr. 339 settings.


2. The orientation command needs the FR-A5AP and FR-A5AX options.

5. FUNCTIONS

5.1 Function Block Diagram

Using function blocks, this section explains I/O data transfer to/from an inverter in PC link operation mode:

- (1) I/O refresh is continuously executed between the master station (AJ71PT32-S3) and inverter at intervals of 3.5ms to 18ms (512 points).
- (2) I/O refresh and master station sequence program are executed asynchronously.
- (3) Input data from the inverter is read from the AJ71PT32-S3 buffer memory by the FROM instruction.
- (4) Output data to the inverter is written to the AJ71PT32-S3 buffer memory by the TO instruction.



1) I/O signals assigned to the AJ71PT32-S3. These signals are used for communication between the PC CPU and AJ71PT32-S3.

For further details of the I/O signals, refer to page 27.

2) Allows input data to be read, output data to be written, and a PC link faulty station to be read, etc. Buffer memory is accessed by the FROM and TO instructions in the sequence program. For full information on the buffer memory, refer to page 30.

3) PC link start is directed from the sequence program. After PC link is initiated, I/O refresh is continually executed independently of the sequence program execution.

5.2 Functions

The following table lists the functions which can be executed from the PC in the PC link operation mode:

Item	Operation Mode		
	PC link operation	External operation	PU operation
Monitoring	Allowed	Allowed	Allowed
Operation	Allowed	Disallowed	Disallowed
Parameter write	Allowed (Note 1)	Disallowed	Disallowed
Parameter read	Allowed	Allowed	Allowed
Inverter reset	Allowed (Note 2)	Disallowed	Disallowed

Note 1. Parameters cannot be written during inverter operation.

2. When a PC link fault occurs, the inverter cannot be reset from the PC.

(1) Monitoring

The following items can be monitored by the PC:

- 1) Output frequency ······ Binary in 0.01Hz increments
- 2) Output current ······· Binary in 0.01A increments
- 3) Output voltage ······· Binary in 0.1V increments
- 4) Alarm definition
- 5) Special monitoring ······ Monitored data selected by instruction code HF3
- 6) Inverter status
 - Forward running ········ Overload (OL)*
 - Reverse running ········ Instantaneous power failure (IPF)*
 - Running (RUN)* ········ Frequency detection (FU)*
 - Up to frequency (SU)* ········ Alarm*

The output signals marked * can be changed using Pr. 190 to Pr. 195 (output terminal function selection).

Note: Items 1) to 5) are read from the buffer memory by setting the corresponding code numbers when needed.
Item 6) can be read from the buffer memory at any time.

(2) Operation commands

Any of the following commands can be output from the PC to the inverter as an operation command at any time:

- Forward rotation (STF)
- Reverse rotation (STR)
- Low speed (RL)^{*1}
- Middle speed (RM)^{*1}
- High speed (RH)^{*1}
- Second acceleration/deceleration (RT)^{*1}
- Inverter output halt (MRS)
- AU terminal^{*1}

The input signals marked *1 can be changed using Pr. 180 to Pr. 186 (input terminal function selection).

(3) Running frequency

The running frequency is written from the PC to the inverter when it is changed ······ Binary in 0.01Hz increments

When changing the frequency continuously, always write the data to the inverter RAM.

The number of E²PROM registration times is limited to "10,000 times".

(4) Parameter write

Functions can be written from the PC. Note that write during inverter operation will result in code mismatch (write mode error).

For the parameter data code list, refer to the inverter manual.

(5) Parameter read

Functions can be read to the PC.

For the parameter data code list, refer to the inverter manual.

6. PROGRAMMING USING THE PC

6.1 Programming

This section describes the programming method for use of MINI link.

(1) I/O list for the PC CPU

The I/O signals of the AJ71PT32 transferred to/from the PC CPU are as indicated below. Numbers following X and Y depend on the head address of the slot being used for the AJ71PT32.

The following I/O numbers assume that the AJ71PT32 is loaded on slot 0 of the main base unit with a building block type CPU.

Device No.	Signal	Device No.	Signal
X0	Hardware fault	Y0 to Y17	Reserved
X1	MINI link communicating	Y18	MINI link communication start
X2	Reserved	Y19	Reserved
X3		Y1A	FROM/TO instruction response designation
X4		Y1B	Faulty station data clear designation
X5	Test mode	Y1C	Reserved
X6	MINI link error detection	Y1D	Error reset
X7	MINI link communication error	Y1E	Reserved
X8 to X1F	Reserved	Y1F	

(2) Programming instructions

1) Since the buffer memory data of the master station is kept transferred (refreshed) to/from the inverters, the TO instruction need not be executed every scan in response to data write or read requests.

The execution of the TO instruction every scan does not pose any problem.

2) 10ms to 30ms after data is written or read, confirmation data and code are written from an inverter to the buffer memory of the master station. At this time, a match check must be made. Otherwise, the previously requested code and data will be read.

3) To prevent a wrong request from being accepted, the inverter accepts a change request and returns change confirmation data and code some time (approx. 10ms) after a request code and data have been changed from the master station. Hence, if a request code and data are changed before the change of the confirmation data and code is completed by the match check, the inverter does not rely on the change request and accordingly does not accept the change request.

When the change is not accepted, the previous confirmation data and code are returned, and data and code mismatch is repeated.

4) By preparing data, the operation commands and data write/read request can be written at the same time. Also, the inverter status, code and data can be read at the same time.

6.1.1 Explanation of I/O signals


This section describes the ON/OFF timings, conditions, etc. of the I/O signals. Device numbers within parentheses correspond to those in the table on page 26.

(1) Hardware fault (X0)

- 1) On indicates that the AJ71PT32's mode setting switch has been set to any of "6 to 9" or a hardware fault has occurred.
- 2) Used as an interlock for the FROM/TO instruction to the AJ71PT32.

(2) MINI link communicating (X1)

- 1) On indicates that the master station (AJ71PT32) has communicated with the remote I/O stations and inverters after Y18 (MINI link communication start) is switched on.
- 2) Switched off when Y18 is switched off.
- 3) Off indicates that a data communication stop error has occurred.
- 4) Used as an interlock to execute the FROM/TO instruction for the AJ71PT32.



(3) Test mode (X5)

On indicates that power is switched on with the mode setting switch in any of "3 to 5".

(4) MINI link error detection (X6) ······ Communication continued

On indicates that the master station has detected an error in receive data from a remote I/O station or an inverter.

1) After X6 is switched on, its state depends on the mode setting as follows:

- Automatic online return mode
X6 is switched off after normal communication is restored.
- No automatic online return mode
X6 remains on.

2) The corresponding error code is stored to buffer memory address 108 when X6 is switched on.
The error code is latched. For further details, refer to page 30.

(5) MINI link communication error (X7) ······ Communication stopped

On indicates that the master station is unable to communicate with remote I/O stations and inverters.

1) X7 is switched on when:

- Any remote I/O station or inverter is switched off;
- Any PC link cable is broken; or
- A communication error has occurred with the mode setting specified for communication stop at the time of online error detection.

2) The corresponding error code is stored to buffer memory address 107 when X7 is switched on.

(6) MINI link communication start (Y18)

1) Switch on to start I/O refresh.

2) X1 is switched on to indicate normal communication with all remote I/O stations.

3) The FROM area (buffer memory addresses 70 to 209) is cleared when Y18 is switched on.

(7) FROM/TO instruction response designation (Y1A)

Defines priority of access to the AJ71PT32 buffer memory.

- 1) Off indicates that the AJ71PT32-S3 processing has priority.
- 2) On indicates that the PC CPU's FROM/TO instruction has priority.
- 3) The ON/OFF status of Y1A defines the following:

FROM/TO Instruction Response Designation (Y1A)	OFF	ON
Item		
Access to buffer memory	Priority given to AJ71PT32-S3.	Priority given to PC CPU's FROM/TO instruction.
Receive (input) data read from several stations by one FROM instruction	The receive data refreshed at the same timing is read.	The receive data refreshed at different timings is read.
FROM/TO instruction processing time	There is a delay of 0.3ms max.	No delay.

(8) Faulty station data clear designation (Y1B)

Specify whether the receive data from a faulty remote I/O station or inverter is cleared or not.

- 1) On indicates that the receive data from a faulty station is cleared.
- 2) Off indicates that the receive data from a faulty inverter is cleared.
- 3) Y1B is independent of the transmission data to a faulty station.

Faulty Station Data Clear Designation (Y1B)	OFF	ON
AJ71PT32 Buffer Memory		
Transmission data (addresses 10 to 41)	———	———
Receive data (addresses 110 to 141)	Data at occurrence of communication error is retained.	All points are switched off.

NOTE

When switching on the faulty station data clear designation signal, it is recommended to set the mode setting switch to the no automatic return mode.

(9) Error reset (Y1D)

Used to reset an error when X6 or X7 is switched on.


- 1) The error indicated by X6 or X7 can be reset by switching on Y1D when Y18 is off.
- 2) Clears the communication error code (buffer memory address 107) and error detection code (address 108).
- 3) Switches off the corresponding input signal (X6, X7).
- 4) ERR. LED reset
Switches off the corresponding error indicator LED (line error LED 4, faulty station LED 5).

6.2 Buffer Memory

The AJ71PT32 has a buffer memory (not battery backed) for communication of data with the PC CPU.
For data transfer using the sequence program, refer to page 41.

(1) Buffer memory assignment

Address (Decimal)



NOTE

- (1) The buffer memory is cleared and 5 is written to address 1 (number of retries) when the PC CPU is switched on or reset.
- (2) Data must not be written to addresses other than 0, 1 and 10 to 41 from the PC CPU.
- (3) The reserved areas are used by the AJ71PT32 system.
- (4) Data in the read-only areas including the reserved areas can be read from the PC CPU sequentially, e.g. data can be read from the cumulative faulty station detection (addresses 90 to 93) and faulty station detection (addresses 100 to 103) areas by using one FROM instruction.

(2) Buffer memory and data location

Buffer memory and data location are described below:

1) Total number of remote I/O stations (address 0)


- (a) Define the remote I/O and inverter station range for I/O refresh.
- (b) I/O refresh is performed for up to the remote I/O stations and inverter stations specified in address 0.
For example, remote I/O stations 1 to 20 are refreshed when 20 is set to address 0.
- (c) Specify the last remote I/O or inverter station number connected to the master station (AJ71PT32-S3).
- (d) Defaults to 0.
- (e) Any value between 1 and 64 may be specified. Any value set outside the range flags an initial data error when Y18 is switched from OFF to ON.
- (f) The total number of remote I/O stations should be written to address 0 with Y18 off as the value on the leading edge of Y18 is valid.

2) Number of retries (address 1)

- (a) Define the number of retries made to the faulty remote I/O station or inverter.
- (b) Defaults to 5.
- (c) Any value between 0 and 32 may be specified.
- (d) The number of retries should be written to address 1 when Y18 is off as the value on the leading edge of Y18 is valid.
- (e) A communication error occurs if the faulty remote I/O station cannot be restored after retry is made the specified number of times.


3) Transmission data (addresses 10 to 41)

- (a) Output to the remote I/O or inverter stations.
- (b) Buffer memory assignment is as follows:



Note: One inverter occupies the addresses of four stations.

(c) Transmission data is made up of 8 bits per remote I/O station as shown below:




1: ON
0: OFF

*: n depends on the remote I/O station number.

b0 to b7 for odd-numbered stations 1, 3, 63

b8 to b15 for even-numbered stations 2, 4, 64

(d) One inverter (PC link unit) has 32 bit locations (for four stations) as shown below:



*: N (odd number) depends on the inverter station number.

(If N is an even number, the program will be complicated.)

· Code Represents a type of data communication such as read, write and parameter number.

For the code list, refer to the inverter manual.

· Operation command b0: AU*

b1 Forward rotation (STF)

b2 Reverse rotation (STR)

b3 Low speed (RL)*

b4 Middle speed (RM)*

b5 High speed (RH)*

b6 Second acceleration/deceleration (RT)*

b7 Inverter output halt (MRS)

1: ON
0: OFF

The input signals marked * can be changed using Pr. 180 to Pr. 186 (input terminal function selection).

· Write data Specific data such as parameter value or running frequency. Any value may be specified when monitoring, parameter read, etc. is executed.

4) Remote I/O station card data (addresses 70 to 77)

- (a) Stores the card data of the I/O units used as the remote I/O stations.
- (b) There are three types of card data which are expressed in two bits.
 - 00: Indicates that there are no remote I/O stations or the station could not make initial communication.
 - 01: Indicates an input remote I/O station or inverter.
 - 10: Indicates an output remote I/O station.
- (c) Data make-up is as indicated below:

	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
70	Station 8	Station 7	Station 6	Station 5	Station 4	Station 3	Station 2	Station 1								
71	Station 16	Station 15	Station 14	Station 13	Station 12	Station 11	Station 10	Station 9								
72	Station 24	Station 23	Station 22	Station 21	Station 20	Station 19	Station 18	Station 17								
76	Station 56	Station 55	Station 54	Station 53	Station 52	Station 51	Station 50	Station 49								
77	Station 64	Station 63	Station 62	Station 61	Station 60	Station 59	Station 58	Station 57								

- (d) Remote I/O station card data is processed only once when Yn+18 is switched from OFF to ON.

5) Cumulative faulty station detection (addresses 90 to 93)

- (a) Sets 1 to the bit corresponding to the faulty remote I/O or inverter station.
- (b) The corresponding bit is not reset to 0 if the faulty station is restored.
 - Addresses 90 to 93 indicate cumulative faulty stations indicated in the faulty station detection area (addresses 100 to 103).
- (c) Reset to 0 when Yn+18 is switched on.
- (d) Data make-up is as indicated below:

	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
90	Station 16	Station 15	Station 14	Station 13	Station 12	Station 11	Station 10	Station 9	Station 8	Station 7	Station 6	Station 5	Station 4	Station 3	Station 2	Station 1
91	Station 32	Station 31	Station 30	Station 29	Station 28	Station 27	Station 26	Station 25	Station 24	Station 23	Station 22	Station 21	Station 20	Station 19	Station 18	Station 17
92	Station 48	Station 47	Station 46	Station 45	Station 44	Station 43	Station 42	Station 41	Station 40	Station 39	Station 38	Station 37	Station 36	Station 35	Station 34	Station 33
93	Station 64	Station 63	Station 62	Station 61	Station 60	Station 59	Station 58	Station 57	Station 56	Station 55	Station 54	Station 53	Station 52	Station 51	Station 50	Station 49

1: Error
0: Normal

6) Faulty station detection (addresses 100 to 103)

- (a) Sets 1 to the bit corresponding to the faulty remote I/O or inverter station.
- (b) In automatic return mode, the corresponding bit is reset to 0 when the faulty station is restored. In no automatic return mode, the corresponding bit remains as 1. Data is held when Y18 is off.
- (c) Any faulty station is detected when Y18 is on.
- (d) Data make-up is as indicated below:

	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
100	Station 16	Station 15	Station 14	Station 13	Station 12	Station 11	Station 10	Station 9	Station 8	Station 7	Station 6	Station 5	Station 4	Station 3	Station 2	Station 1
101	Station 32	Station 31	Station 30	Station 29	Station 28	Station 27	Station 26	Station 25	Station 24	Station 23	Station 22	Station 21	Station 20	Station 19	Station 18	Station 17
102	Station 48	Station 47	Station 46	Station 45	Station 44	Station 43	Station 42	Station 41	Station 40	Station 39	Station 38	Station 37	Station 36	Station 35	Station 34	Station 33
103	Station 64	Station 63	Station 62	Station 61	Station 60	Station 59	Station 58	Station 57	Station 56	Station 55	Station 54	Station 53	Station 52	Station 51	Station 50	Station 49

1: Error
0: Normal


7) Communication error code (address 107)

- (a) Stores the corresponding error code when X7 is switched on.
- (b) Communication error codes are as follows:


Code	Definition	Cause
0	No error	—————
1	Initial data error	The number of remote I/O stations or retries is invalid.
2	Line error	A link cable is broken or a remote I/O or inverter station power is off.
3	Station fault	Communication has stopped due to a station fault with communication stop mode specified for fault detection.

- (c) The communication error code is reset to 0 when Y18 or Y1D is switched on.

- 8) Error detection code (address 108)
- (a) 1 indicates that X6 has been switched on. 0 indicates normal.
 - (b) In automatic return mode (mode setting switch: 0), the error detection code remains 1 but X6 is switched off when communication is restored.
 - (c) Reset to 0 when Y18 or Y1D is switched on.
- 9) Receive data (addresses 110 to 141)
- (a) Stores the ON/OFF data input to the remote I/O and inverter stations.
 - (b) Buffer memory assignment is as indicated below:




(c) Receive data is made up of 8 bits per remote I/O station as shown below:



*: n depends on the remote I/O station number.
 b0 to b7 for odd-numbered stations 1, 3, 63
 b8 to b15 for even-numbered stations 2, 4, 64

(d) One inverter (PC link unit) has 32 bit locations (for four stations) as shown below:



- Code ······ Represents a type of data communication such as read, write and parameter number.
For the code list, refer to the inverter manual.
- Inverter status
 - b0 ······ Running (RUN)*
 - b1 ······ Forward running
 - b2 ······ Reverse running
 - b3 ······ Up to frequency (SU)*
 - b4 ······ Overload (OL)*
 - b5 ······ Instantaneous power failure (IPF)*
 - b6 ······ Frequency detection (FU)*
 - b7 ······ Alarm*

1: ON
0: OFF

The output signals marked * can be changed using Pr. 190 to Pr. 195 (output terminal function selection).

- Read data ······ Data corresponding to the code definition is received and stored from the inverter.

10) Line error retry counter (address 160)


- (a) Stores the number of retries made after a line error has occurred.
- (b) Reset to 0 when communication is restored.
- (c) Stores the value from address 1 (number of retries) when X7 is switched on.

11) Retry counter (addresses 161 to 192)

- (a) Receives the number of retries made to the faulty remote I/O or inverter station.
- (b) Reset to 0 when communication is restored.
- (c) Buffer memory assignment is as indicated below:

	b15 to b8	b7 to b0
161	Station 2	Station 1
162	Station 4	Station 3
163	Station 6	Station 5
⋮		
191	Station 62	Station 61
192	Station 64	Station 63

- (d) The retry counter is made up of 8 bits per remote I/O station as shown below:




*: n depends on the station number.
 b0 to b7 for odd-numbered stations 1, 3, 63
 b8 to b15 for even-numbered stations 2, 4, 64

6.3 Programming Procedure

In MINI link, write initial data (the total number of remote I/O stations at address 0 and the number of retries at address 1) to the master station (AJ71PT32) buffer memory to perform I/O refresh.

The initial data must be written before Y18 is switched on.

Example



6.4 Programming Examples

This section describes specific programming examples such as inverter operation, monitoring, and parameter read and write.


(1) Writing the initial data

Note the following when writing the initial data of MINI link to the master station (AJ71PT32) buffer memory.

- 1) The initial data includes the total number of remote I/O stations (address 0) and the number of retries (address 1).
- 2) The total number of remote I/O stations may be set between 1 and 64, and defaults to 0.
- 3) The number of retries may be set between 0 and 32, and defaults to 5.
- 4) The initial data should be written when Y18 is off. If the initial data is changed with Y18 on, the I/O refresh condition remains unchanged.

5) Program example

The following program operates only two inverters with the master station (AJ71PT32) loaded on slot 0:




(2) Reading the inverter status

Write a program as explained below to read the inverter status from the master station buffer memory:

- 1) The inverter status exists in the receive data area (addresses 111 to 141).

2) Program example

The following program reads the inverter status of station 1 to M0-7:




(3) Writing the operation commands


Write a program as explained below to write the inverter operation commands to the master station buffer memory:

1) The inverter is operated in accordance with the operation commands written to the transmission data area (addresses 10 to 41).

2) Program example

The following program outputs the commands of forward rotation and middle speed signals to station 5 inverter:






(4) Reading data

Write programs as explained below to read various data from the inverters:

1) Procedure




Note 1. The previous data may be read if the required data is read immediately after the code is written. Data should be read after the transmission data code has matched the receive data code.

Note 2. If the codes do not match after retry is repeated, take appropriate action after checking the mismatch definition on page 50.

2) Monitoring program example

- The following program reads the output frequency of station 5 inverter to D1.
Output frequency reading code number: H6F (hexadecimal)




● Monitoring codes

Item	Code	Data Type	Data Unit
Output frequency	H6F	Hexadecimal	0.01Hz
Output current	H70	Hexadecimal	0.01A
Output voltage	H71	Hexadecimal	0.1V

Example: The output frequency of 60Hz is indicated H1770 (6000).

3) Parameter reading program example


- The following program reads the acceleration time setting of station 5 inverter to D1.
Acceleration time reading code number: H07 (hexadecimal)



For other parameters, refer to the "data code list" in the inverter manual.


4) Alarm definition reading program example

- The following program reads the alarm definition of station 5 inverter to D1.
Alarm definition reading code number: H74 (hexadecimal)



● Alarm definition display example

Example: Read data is H030A — Previous alarm ... THT
Current alarm ... OPT



● Alarm data

For full information on alarm definition, refer to the inverter manual.

Data	Definition	Data	Definition	Data	Definition
H00	No alarm	H05	IPF	H0B	PE
H01	OC1	H15	UVT	H1B	PUE
H11	OC2	H06	OLT	H2B	RET
H21	OC3	H07	BE	H0C	CPU
H02	OV1	H08	GF	H1C	CTE
H12	OV2	H81	LF	H2C	P24
H22	OV3	H09	OHT	H5D	MB1
H03	THT	H0A	OPT	H6D	MB2
H13	THM	H1A	OP1	H7D	MB3
H04	FIN	H2A	OP2	H8D	MB4
H14	—	H3A	OP3	H9D	MB5
				HAD	MB6
				HBD	MB7


5) Code mismatch definition reading program example

- The following program reads the code mismatch definition of station 5 inverter when code mismatch is repeated during output current read.

Example

Output current reading code number: H70 (hexadecimal)

Code mismatch definition reading code number: H7E (hexadecimal)




● Code mismatch definition

Data	Item	Alarm Definition
H0000	Code under recognition	Match check is being performed in the inverter.
H0001	Write mode error	Parameter write was attempted during other than stop in PC link operation mode.
H0002	Parameter select error	Invalid code number has been set.
H0003	Setting range error	Set data is outside the permissible range.

(6) Writing data

Write programs as explained below to write various data to the inverters:

1) Procedure




Note: Both the codes and data must be checked to ensure that they are correct. If code and data mismatch is repeated, check the mismatch definition on page 49.

2) Operation mode switching program example

- The following program changes the operation mode of station 5 inverter to PC link operation.

Operation mode setting code number: HFB (hexadecimal)

PC link operation set data: H0000 (hexadecimal)



- Operation mode setting

Code number: HFB

Set data0000: PC link operation


0001: External operation

(0002: PU operation)

Note: PU operation cannot be set from the PC.

3) Running frequency setting program example


- The following program changes the running frequency of station 5 inverter to 50.00Hz.
 Running frequency setting code number: HEE (hexadecimal)
 Set frequency: K5000 (decimal)



- To continuously change the running frequency from PC
 The set data match check is not required but the code match check should be made. The above program writes the frequency set data to E²ROM of the inverter. When the output frequency is changed continuously, running frequencies should be written to the inverter RAM as the number of write times to E²ROM is limited.
 Program example for writing to RAM
 Modify the above program as follows:
 Change the running frequency setting code number from HEE to HED.

4) Parameter writing program example


- The following program changes the acceleration time setting of station 5 inverter to 3.0 seconds.
 Acceleration time writing code number: H87 (hexadecimal)
 Acceleration time set data: K30 (decimal)



- For other parameters, refer to the "data code list" in the inverter manual.

5) Inverter resetting program example

- The following program resets the inverter of station 5.
 Inverter resetting code number: HFD (hexadecimal)
 Inverter resetting set data: H9696 (hexadecimal)



● Other program examples

Change the code number HFD of the above program as follows:

Function	Code Number
All parameter clear	HFC
Alarm definition batch clear	HF4

Note: All clear function

In code number HFC, note that the execution differs with the set data as described below:

Data	Execution
H9669	Clears user-set parameters.
H9696	Returns parameters to the factory settings (initial values) with the exception of some parameters (calibration values ····· Pr. 900 to Pr.905).
H9966	Returns all parameters to the factory settings (initial values).

6.5 Setting Items and Set Data

After completion of parameter setting, set the instruction codes and data as indicated below and start communication from the computer to allow various types of operation control and monitoring.

No.	Item		Instruction Code		Description						
1	Operation mode	Read	H7B		H0001: External operation H0002: Communication operation						
		Write	HFB		H0001: External operation H0002: Communication operation						
2	Monitoring	Output frequency [speed]		H6F	H0000 to HFFFF: Output frequency (hexadecimal) in 0.01Hz increments [Speed (hexadecimal) in 1r/min increments if Pr. 37 = 1 to 9998 or Pr. 144 = 2 to 10, 102 to 110.]						
		Output current		H70	H0000 to HFFFF: Output current (hexadecimal) in 0.01A increments						
		Output voltage		H71	H0000 to HFFFF: Output voltage (hexadecimal) in 0.1V increments						
		Special monitor		H72	H0000 to HFFFF: Monitored data selected by instruction code HF3						
		Special monitor selection No.		Read	H73	H0001 to H000E: Monitor selection data					
						Data	Description	Increments	Data	Description	Increments
						H0001	Output frequency	0.01Hz	H000A	Electronic overcurrent protection load factor	0.1%
				H0002	Output current	0.01A					
				H0003	Output voltage	0.1V	H000B	Output current peak value	0.01A		
				H0005	Frequency setting	0.01Hz					
H0006	Running speed			1r/min	H000C	Converter output peak value	0.1V				
H0007	Motor torque			0.1%							
Write	HF3			H0009	Regenerative brake	0.1%	H000D	Input power	0.01kW		
							H000E	Output power	0.01kW		

No.	Item	Instruction Code	Description																																																																														
2	Monitoring Alarm definition	H74 to H77	<p>H0000 to HFFFF: Two most recent alarm definitions Alarm definition display example (instruction code H74) Read data: [Example] H30A0</p> <p>(Previous alarm THT) $\overbrace{\text{b15} \quad \text{b8b7} \quad \text{b0}}$ (Most recent alarm OPT) $\overbrace{\text{00111000001010100000}}$</p> <p>Alarm data</p> <table border="1"> <thead> <tr> <th>Data</th> <th>Description</th> <th>Data</th> <th>Description</th> <th>Data</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>H00</td> <td>No alarm</td> <td>H05</td> <td>IPF</td> <td>H1C</td> <td>CTE</td> </tr> <tr> <td>H01</td> <td>OC1</td> <td>H15</td> <td>UVT</td> <td>H2C</td> <td>P24</td> </tr> <tr> <td>H11</td> <td>OC2</td> <td>H06</td> <td>OLT</td> <td>H5D</td> <td>MB1</td> </tr> <tr> <td>H21</td> <td>OC3</td> <td>H07</td> <td>BE</td> <td>H6D</td> <td>MB2</td> </tr> <tr> <td>H02</td> <td>OV1</td> <td>H08</td> <td>GF</td> <td>H7D</td> <td>MB3</td> </tr> <tr> <td>H12</td> <td>OV2</td> <td>H18</td> <td>LF</td> <td>H8D</td> <td>MB4</td> </tr> <tr> <td>H22</td> <td>OV3</td> <td>H09</td> <td>OHT</td> <td>H9D</td> <td>MB5</td> </tr> <tr> <td>H03</td> <td>THT</td> <td>H0A</td> <td>OPT</td> <td>HAD</td> <td>MB6</td> </tr> <tr> <td>H13</td> <td>THM</td> <td>H0B</td> <td>PE</td> <td>HBD</td> <td>MB7</td> </tr> <tr> <td>H04</td> <td>FIN</td> <td>H1B</td> <td>PUE</td> <td>H1A</td> <td>OP1</td> </tr> <tr> <td>H14</td> <td>—</td> <td>H2B</td> <td>RET</td> <td>H2A</td> <td>OP2</td> </tr> <tr> <td></td> <td></td> <td>H0C</td> <td>CPU</td> <td>H3A</td> <td>OP3</td> </tr> </tbody> </table> <p>Previous alarm (H03) Most recent alarm (H0A)</p>	Data	Description	Data	Description	Data	Description	H00	No alarm	H05	IPF	H1C	CTE	H01	OC1	H15	UVT	H2C	P24	H11	OC2	H06	OLT	H5D	MB1	H21	OC3	H07	BE	H6D	MB2	H02	OV1	H08	GF	H7D	MB3	H12	OV2	H18	LF	H8D	MB4	H22	OV3	H09	OHT	H9D	MB5	H03	THT	H0A	OPT	HAD	MB6	H13	THM	H0B	PE	HBD	MB7	H04	FIN	H1B	PUE	H1A	OP1	H14	—	H2B	RET	H2A	OP2			H0C	CPU	H3A	OP3
Data	Description	Data	Description	Data	Description																																																																												
H00	No alarm	H05	IPF	H1C	CTE																																																																												
H01	OC1	H15	UVT	H2C	P24																																																																												
H11	OC2	H06	OLT	H5D	MB1																																																																												
H21	OC3	H07	BE	H6D	MB2																																																																												
H02	OV1	H08	GF	H7D	MB3																																																																												
H12	OV2	H18	LF	H8D	MB4																																																																												
H22	OV3	H09	OHT	H9D	MB5																																																																												
H03	THT	H0A	OPT	HAD	MB6																																																																												
H13	THM	H0B	PE	HBD	MB7																																																																												
H04	FIN	H1B	PUE	H1A	OP1																																																																												
H14	—	H2B	RET	H2A	OP2																																																																												
		H0C	CPU	H3A	OP3																																																																												
3	Operation command	HFA	<p>H00 to HFF: Operation command</p> <p>$\overbrace{\text{b15} \quad \text{b7} \quad \text{b0}}$ $\overbrace{\text{000000000000000010}}$</p> <p>(For example 1) [Example 1] H02 ... Forward rotation [Example 2] H00 ... Stop</p> <p>b0: AU* b1: Forward rotation (STF) b2: Reverse rotation (STR) b3: RL* b4: RM* b5: RH* b6: RT* b7: MRS</p> <p>The input signals marked * change with the settings of Pr. 180 to Pr. 186 (input terminal function selection).</p>																																																																														

No.	Item	Instruction Code	Description															
4	Inverter status monitor	H7A	<p>H00 to HFF: Inverter status monitor</p> <p style="text-align: center;"> b7 b0 00000010 </p> <p>(For example 1) [Example 1] H02 ... Forward running [Example 2] H00 ... Stop due to alarm occurrence</p> <p>b0: Inverter running (RUN)* b1: Forward running (STF) b2: Reverse running (STR) b3: Up to frequency (SU)* b4: Overload (OL)* b5: Instantaneous power failure (IPF)* b6: Frequency detection (FU)* b7: Alarm occurrence*</p> <p>*: Outputs change with the settings of Pr. 190 to Pr. 195 (output terminal function selection).</p>															
5	Running frequency write (E ² ROM)	HEE	<p>H0000 to H9C40: 0.01Hz increments (hexadecimal) (0 to 400.00Hz) To change the running frequency consecutively, write data to the inverter RAM. (Instruction code: HED)</p>															
6	Inverter reset	HFD	<p>H9696: Resets the inverter. As the inverter is reset on start of communication by the computer, the inverter cannot send reply data back to the computer.</p>															
7	All clear	HFC	<p>All parameters return to the factory settings. Any of four different clear operations is performed according to the data.</p> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="border: none;">Parameter Data</th> <th>Communication Pr.</th> <th>Calibration Pr.</th> <th>Other Pr.</th> <th>HEC HF3 HFF</th> </tr> </thead> <tbody> <tr> <td style="border: none;">H9696</td> <td>○</td> <td>×</td> <td>○</td> <td>○</td> </tr> <tr> <td style="border: none;">H9966</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> </tbody> </table> <p>When all clear is executed with H9696 or H9966, RS-485 communication-related parameter settings also return to the factory settings. When using RS-485 communication, make parameter settings again.</p>	Parameter Data	Communication Pr.	Calibration Pr.	Other Pr.	HEC HF3 HFF	H9696	○	×	○	○	H9966	○	○	○	○
Parameter Data	Communication Pr.	Calibration Pr.	Other Pr.	HEC HF3 HFF														
H9696	○	×	○	○														
H9966	○	○	○	○														

No.	Item	Instruction Code	Description								
8	User clear	HFC	H9669: User clear is made. <table border="1"> <tr> <td>Communication Pr.</td> <td>Calibration Pr.</td> <td>Other Pr.</td> <td>HEC HF3 HFF</td> </tr> <tr> <td>○</td> <td>×</td> <td>○</td> <td>○</td> </tr> </table>	Communication Pr.	Calibration Pr.	Other Pr.	HEC HF3 HFF	○	×	○	○
Communication Pr.	Calibration Pr.	Other Pr.	HEC HF3 HFF								
○	×	○	○								
9	Parameter write	H80 to HE3	Write and/or read parameter values as required.								
10	Parameter read	H00 to H63	Note that some parameters may not be accessible.								
11	Link parameter expansion setting	Read	H7F H00 to H6C and H80 to HEC parameter values are changed. H00: Pr. 0 to Pr. 99 values are accessible.								
		Write	HFF H01: Pr. 100 to Pr. 159, Pr. 200 to Pr. 231 and Pr. 900 to Pr. 905 values are accessible. H02: Pr. 160 to Pr. 199 and Pr. 232 to Pr. 285 values are accessible. H09: Pr. 990 value is accessible.								
12	Second parameter changing (Code FF=1)	Read	H3D to H5A HBD to HAD (Code FF = 1) H00: Running frequency H01: Time H02: Rotation direction								
		Write	H5E to H6A HDE to HED (Code FF = 1) H00: Offset/gain H01: Analog H02: Analog value of terminal								

7. ALARM

7.1 Alarm

This section explains the corrective action and restoration method after an alarm has occurred.

(1) Alarm occurrence

Alarms occurring in each operation mode results in the following:

	Operation Mode		
	PC link operation	External operation	PU operation
Inverter fault	Inverter stopped. Data communication continued.	Inverter stopped. Data communication continued.	Inverter stopped. Data communication continued.
PC link error	Inverter stopped. Data communication stopped.	Inverter operation continued. Data communication stopped.	Inverter operation continued. Data communication stopped.

(2) Checking alarm definition

Check the alarm definition in the procedure given on page 48.

1) Inverter fault

Remove the cause of alarm in accordance with the inverter manual.

2) Line error, data communication stop

In the inboard option unit, check that:

- The optical cable connectors are fitted correctly;
- The optical cables are not open; and
- The inboard option unit is fitted correctly in the inverter connector.

If the above faults are not found, check the master station in accordance with Section 4.6 of the MELSECNET/MINI-S3 user's manual (master station).

(3) Restoration

Reset the inverter after removing the cause of the alarm.

Even if the main circuitry of an inverter has been damaged, the other inverters in the same loop can perform PC link operation when the control power is live.

(4) Resetting method

Reset is allowed or disallowed as indicated below:

Resetting Method	Operation Mode		
	PC link operation	External operation	PU operation
PC user program (refer to page 55)	Allowed*1	Disallowed	Disallowed
Connect terminals RES-SD	Allowed	Allowed	Allowed
Switch off inverter power	Allowed	Allowed	Allowed

*1. The inverter cannot be reset from the PC if a line error has occurred.

After resetting, the inverter is set to either of the following operation modes depending on the setting of Pr. 79:

When Pr. 79 setting is "0" or "2" ····· External operation mode

When Pr. 79 setting is "1" ········· PU operation mode

Note: The inverter is set to the external operation mode if it has been reset from the PC in the PC link operation mode. To resume the PC link operation, therefore, the inverter must be switched to the PC link operation mode. (For the operation mode switching, refer to page 16.)

(5) Troubleshooting

1) Operation mode does not switch to PC link

- Check that the PC link unit and optical cables are fitted properly.
(Check for contact fault, open cable, wrong polarity, etc.)
- Check that the station number setting switches are set to the correct positions. (Check that the station number matches the program, the station numbers are not repeated, and the station number is not outside the range.)
- Check that the inverter is in the external operation mode.
- Check that the RUN indicator LED is on.
- Check that the operation mode switching program is run.
- Check that the operation mode switching program has been written correctly.

2) Inverter unstarted in PC link mode

- Check that the inverter is in the PC link operation mode.
- Check that the inverter starting program has been written correctly.
- Check that the inverter starting program is run.
- Check that the inverter is providing output.

3) Communication stops during operation

- Check that the PC link unit and optical cables are fitted properly.
(Check for contact fault, open cable, etc.)
- Check that the programmable controller program is executed reliably and that the PC CPU is running.
- Check that data communication has not stopped due to an instantaneous power failure, etc.
- Check that the communication start signal (Yn+18) of the master station is on.

8. SPECIFICATIONS

8.1 Performance Specifications

Item		Specifications	
PC link system		MELSECNET/MINI-S3 system	
PC side*1	Applicable CPU card	1. A0J2CPU, A0J2HCPU (extension base required) 2. A1SJCPU-S3, A1SJHCPU, A1SCPU, A1SHCPU 3. A2SCPU, A2SHCPU, A2USCPU(-S1), A2USHCPU-S1 4. AnN, AnA, AnUCPU	
	Master station	Type	AJ71PT32-S3 optical link module (remote I/O mode, remote terminal mode possible), A1SJ71PT32-S3
		Number of link stations	64 stations max. (8 points/station), max. link points = 512
		Refresh time	3.5ms to 18ms (when 64 stations are connected)
Communication cable		Plastic optical fiber cable	
Max. interstation transmission distance		50m	
Inverter side	Type	Inboard options fitted to the connector in the inverter	
	Power supply	5VDC supplied from the inverter	
	Number of inverters connected	16 inverters max. (4 stations occupied by 1 inverter). May be used with other equipment.	

*1. For the PC specifications, refer to the MELSECNET/MINI-S3 user's manual. The MINI link system does not have a loopback function as it has only one loop of PC link cables.

8.2 Optical Fiber Cable Specifications

The following table lists the specifications for the optical fiber cable for PC link:

Item	Specifications
Optical cable used	Plastic fiber cable
Communication speed	1.5MBPS
Minimum optical transmission level	-15dBm
Maximum optical transmission level	-31dBm
Light wavelength	660nm (visible light)
Optical fiber OD	1mm
Connector	1-core connector
Cable transmission loss	260dB/km max.

8.3 Inverter I/O Delay Time

The following I/O signal delays may occur in the MINI link:

1) The following delays may occur until the PC CPU reads an input signal from the inverter:

(a) Inverter response time

Indicates a period of time required for the inverter to be switched from ON to OFF or from OFF to ON. (FR-A5NN: Approx. 10ms to 30ms)

(b) MINI link I/O refresh time

For full information, refer to Section 4.2 in the AJ71PT32-S3 user's manual.

(c) FROM instruction processing time

There is a maximum of one scan delay if the FROM instruction is executed once during a scan of the sequence program, for example.

2) The following delays may occur until the PC CPU outputs a command to the inverter:

(a) TO instruction processing time

There is a maximum of one scan delay if the TO instruction is executed once during a scan of the sequence program, for example.

(b) MINI link I/O refresh time

(c) Inverter response time

Indicates a period of time required for the inverter to be switched from ON to OFF or from OFF to ON.

(FR-A5NN: Approx. 10ms to 30ms)

NOTE

The I/O delay time of the inverter depends on the FROM/TO instruction processing time (1)-(c) or 2)-(a)).

Where the I/O delay time does not pose any problem, the FROM/TO instruction is executed once during a scan.

The I/O delay time can be reduced by writing the program as described below:

- 1) To reduce the input delay time, execute the FROM instruction immediately before the input signal is used in the sequence program.
- 2) To reduce the output delay time, execute the TO instruction after the sequence program operation is performed.

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Oct, 1997	IB(NA)-66834-A	First edition